



MODEL: X2550016D RESIN BIRD BATH

PARTS LIST



ASSEMBLY INSTRUCTIONS

NOTES:

- 1. PLEASE READ THE ASSEMBLY INSTRUCTIONS CAREFULLY BEFORE YOU ASSEMBLE.
- 2. MAKE SURE YOU HAVE ALL THE PARTS AS IDENTIFIED ON THE PARTS LIST.
- 3. NO TOOLS REQUIRED.

SET UP:

- (1) CONNECT THE POLE (P3) AND THE CONNECTOR (P4) TOGETHER BY SCREWING.
- (2) CONNECT THE BASE (P5) AND THE CONNECTOR (P4) TOGETHER BY SCREWING.
- (3) CONNECT THE BASIN (P2) AND THE TOP OF THE POLE (P3) TOGETHER BY SCREWING.
- (4) INSERT THE BIRDS (P1) INTO THE HOLES ON THE BASIN (P2).
- (5) NOW THE BIRD BATH IS READY FOR USE.

