

VIBRATING MASSAGER

Operating instructions:

1. Remove battery cover on the underside of the massager and insert 2 "AA" batteries (not included) .



WARNING:

Do not mix old and new batteries.
Do not mix alkaline,
standard (carbon-zinc) or rechargeable
(nickel cadmium) batteries.

2. Close the battery cover until the cover "clicks" close.
3. Press the thumb to turn the massager ON or OFF.

Function:

- Invigorating massage action with or without the motor turned on..
- Battery powered-use 2 X "AA" batteries (not included).
- Just push nail of the thumb to turn on/off this device.
- Great for back, neck , shoulders, legs and arms.

Specification:

Battery : 2 X "AA" batteries (not included)

Material: ABS plastic

Note: *This is not a toy, keep out of reach of children.*