








fourstargroup



**MODEL:11203630FM**

**WOOD ACCENT TABLE**


## PARTS AND HARDWARE

<b>A.</b>	<b>TOP SHELF (1 pc.)</b>	
<b>B.</b>	<b>LOWER SHELF (1 pc.)</b>	
<b>C.</b>	<b>UPPER SPINDLE LEGS (4 pcs.)</b>	
<b>D.</b>	<b>LOWER SPINDLE LEGS (4 pcs.)</b>	

# ASSEMBLY INSTRUCTIONS

**NOTE: ASSEMBLE THE TABLE ON A CLEAN, SMOOTH SURFACE, SUCH AS A CARPET.**

- 1) Attach the **UPPER SPINDLE LEGS (C)** to the **TOP (A)**, as shown.
- 2) Attach **LOWER SHELF (B)** to the **UPPER SPINDLE LEGS (C)** by turning **LOWER SPINDLE LEGS (D)**, as shown.



Do you have any questions ? Missing small parts or hardware ?  
If you need assistance with the assembly of your SOLID WOOD  
ACCENT TABLE please e-mail our Customer Service  
Department at:  
[support@fourstari.com](mailto:support@fourstari.com)  
or call us at (508) 435-4830  
or (800) 639-3803

Please include the following information in your email:

- Where item was purchased
- Item, model, style or SKU number listed on instructions or box
- Part number, description of the part and quantity needed

This information will help us get the proper part to you faster