

## PARTS LIST

NO	PARTS LIST		QTY
Α	SUPPORT BASE		1 PC
В	LOWER SUPPORT BAR		1 PC
С	UPPER SUPPORT BAR		1 PC
D	TILT PLATE		1 PC
Е	LINK	E Co	2 PCS
F	TOP PANEL		1 PC
G	BOLT 25MM	Guu	2 PCS
Н	BOLT 10MM	ய	6 PCS
Ι	NUT	۲	2 PCS
J	HEAD BOLT (8MM)		1 PC
K	WASHER	0	1 PC
L	HEAD BOLT (6MM)		1 PC
М	CASTOR	6	2 PCS
Ν	LOCKING CASTOR	67	2 PCS
0	SMALL WRENCH		1 PC
Р	LARGE WRENCH	<u>S</u>	1 PC
Q	ALLEN WRENCH	Ĺ,	1 PC


# **ASSEMBLY INSTRUCTIONS**


**CAUTION:** 

**1. READ THIS INSTRUCTION MANUAL BEFORE YOU ASSEMBLE.** 


2. ASSEMBLE ON SOFT SURFACE TO PREVENT DAMAGE TO THE PRODUCT FINISH.

### STEP 1 ATTACH CASTORS (M) AND LOCKING CASTORS (N) TO SUPPORT BASE (A) WITH LARGE WRENCH (P) AS SHOWN.






### STEP 4 ATTACH UPPER SUPPORT BAR (C) TO TOP PANEL (F) USING LINKS (E) AND BOLTS (H) WITH PROVIDED ALLEN WRENCH (O) AS SHOWN.



#### STEP 5 ATTACH STEP 4 COMPLETED ASSEMBLY TO STEP 2 COMPLETED ASSEMBLY USING HEAD BOLT (L) AS SHOWN.



Do you have any questions? Missing small parts or hardware?

If you need assistance with the assembly of your LAPTOP DESK

#### please e-mail our Customer Service Department at: support@fourstari.com

or call us at (508) 435-4830

or (800) 639-3803

- Please include the following information in your email:
- Where item was purchased
- Item, model, style or SKU number listed on instructions or box

• Part number, description of the part and quantity needed

This information will help us get the proper part to you faster.