

MODEL: 11221435B STYLE: 675857

COMPUTER TABLE

Distributed by: Fourstar Group, Inc.
Made in China

Do you have any questions? Missing small parts or hardware? If you need assistance with the assembly of your COMPUTER TABLE please e-mail our Customer Service Department at: support@fourstari.com or call us at (508) 435-4830 or (800) 639-3803. Both hotlines are available from 9 AM to 5 PM (EST)

PARTS AND HARDWARE

PRECAUTIONS:

- 1. PLEASE READ THE INSTRUCTIONS BEFORE ASSEMBLY.
- 2. THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.
- 3. PLEASE CHECK AND MAKE SURE THE PARTS IN THE TABLE BELOW ARE INCLUDED IN THE PACKAGING.
- 4. A CROSS HEAD SCREWDRIVER AND GLOVES ARE NEEDED DURING THE ASSEMBLY.
- 5. DON'T TIGHTEN THE SCREWS BEFORE ALL SCREWS ARE IN PLACE.


WARNING: DO NOT PLACE ANY WEIGHT OVER 150 LBS ON THE GLASS TABLETOP AND OVER 30 LBS ON ANY SHELF.

30 LBS ON ANY SHELF.			
1	2	3	4
	··		-
Printer Shelf - 1 PC	Bookshelf - 1 PC	Displayer Shelf - 1 PC	Glass Tabletop - 1 PC
CD Holder 2 PCS	6 Straight Steel Bar - 1 PC	7 Curve Steel Bar - 1 PC	Back Tube of Table 1 PC
9 Front Tube of Table	10	11	12
1 PC	Support A - 2 PCS	Support B - 3 PCS	Leg - 2 PCS
13 · · · · · · · · · · · · · · · · · · ·	14	15	16
Table Frame Connector - 2 PCS	Keyboard Panel - 1 PC	Right Slider - 1 PC	Left Slider - 1 PC
17	18	A	В
Washer - 5 PCS	Back Panel - 1 PC	Black M6x65 - 8 PCS	White M6x45 - 9 PCS
C	D D	E	F (S)
M6x10 - 14 PCS	M6x25 - 4 PCS	Nut - 4 PCS	Screw - 4 PCS
G	H	I	J
Suction Cup - 4 PCS	Rubber Foot - 4 PCS	CD Holder Pad 2 PCS	Allen Wrench - 1 PC

ASSEMBLY INSTRUCTIONS


STEP 1

Screw the Rubber Foot (H) into Leg (12).




STEP 2

Connect the Back Panel(18) to the two Legs (12).




STEP 3

Attach Back Tube of Table (8) and Front Tube of Table (9) by the Table Frame Connector (13).




STEP 4

Fasten the Support A (10) and Support B (11) to the Bookshelf (2) and Displayer Shelf (3).




STEP 5

Attach Support A (10) and Support B (11) to Back Tube of Table (8) and secure them with White Screw (B) and Washer (17).




STEP 6

Tap the Straight Steel Bar (6) into Bookshelf (2) and Curve Steel Bar (7) into Displayer Shelf (3). Tighten each with Nut (E).




STEP 7

Connect CD Holders (5) and CD Holder Pads (I) to Bookshelf (2).




STEP9

Join the keyboard Right Slider (15) and Left Slider (16) to table frame.




STEP8

Attach the Printer Shelf (1) to CD Holders (5).




STEP 10

Using Screws (F), screw Keyboard Panel (14) into the Sliders (15 & 16).




STEP 11

Place four Suction Cups (G) onto Slider and attach the Glass Tabletop (4) to the table frame.



STEP 12

Tighten all of the screws. Now the assembly is finished.



Do you have any questions? Missing small parts or hardware? If you need assistance with the assembly of your COMPUTER TABLE please e-mail our Customer Service Department at: support@fourstari.com or call us at (508) 435-4830 or (800) 639-3803 Both hotlines are available from 9 AM to 5 PM (EST)

Please include the following information in your email:

- Where item was purchased
- Item, model, style or SKU number listed on instructions or box
- Part number, description of the part and quantity needed

This information will help us get the proper part to you faster.