


















fourstargroup



MODEL: 11223764DT

WOODEN BOOKSHELF

PARTS LIST AND HARDWARE

NO	HARDWARE LIST	QTY	
A		SIDE FRAME	2PCS
B		BACK BAR	1PC
C		MIDDLE BAR	1PC
D		CROSS BAR	2PCS
E		SIDE BAR	2PCS
F		SIDE BAR	1PC
G		SIDE BAR	1PC
H		SIDE BAR	4PC
I		FEET	4PCS
J		UPPER PANEL	2PCS
K		BOTTOM PANEL	1PC
L		BOLT	2PCS
M		WOOD DOWEL	2PCS
N		ALLEN WRENCH	1PC


ASSEMBLY INSTRUCTIONS


CAUTION:

1. READ THIS INSTRUCTION MANUAL BEFORE YOU ASSEMBLE SET.
2. ASSEMBLE ON SOFT SURFACE TO PREVENT DAMAGE TO FINISH OF PRODUCT.

STEP

- 1.1 ATTACH BACK BAR (B) TO SIDE FRAMES (A) USING WOOD DOWELS (M) AND BOLTS (L) WITH PROVIDED ALLEN WRENCH (N) AS SHOWN.
- 1.2 TAKE SIDE BARS (E, F, G) THROUGH UPPER PANEL (J), SCREW INTO SIDE FRAMES (A), THEN INSERT CROSS BARS (D) BETWEEN SIDE BARS (E) &(F), INSERT BACK BAR (C) BETWEEN SIDE BARS (F) &(G).
- 1.3 TAKE SIDE BARS (H) THROUGH UPPER PANEL (J), SCREW INTO SIDE BARS (E, F, G) AS SHOWN.
- 1.4 ATTACH BOTTOM PANEL (K) TO 1.3 FINISHED USING FEET (I) AS SHOWN.







MAXIMUM LOADING CAPACITY OF EACH SHELF IS 20 LBS.

IF NECESSARY, PLEASE FOLLOW BELOW INSTRUCTION TO PREVENT PRODUCT TIP OVER.

PARTS

HARDWARE LIST			QTY
			2 SETS
WALL PLUG	EYELET SCREW	CABLE TIE	



Do you have any questions? Missing small parts or hardware?
 If you need assistance with the assembly of your WOODEN BOOKSHELF please e-mail our Customer Service Department at: support@fourstari.com or call us at (508) 473-7688 or (800) 639-3803

Please include the following information in your email:

- Where item was purchased
- Item, model, style or SKU number listed on instructions or box
- Part number, description of the part and quantity needed

This information will help us get the proper part to you faster