




**MODEL: 11260132
COMPUTER DESK AND
STORAGE SHELF**



BEFORE YOU BEGIN, PLEASE READ ASSEMBLY INSTRUCTIONS CAREFULLY. FOLLOW THEM STEP BY STEP.


CAUTION:

1. ADULT SUPERVISION IS REQUIRED DUE TO SMALL PARTS. CARE SHOULD BE TAKEN IN THE UNPACKING AND ASSEMBLY OF THE PRODUCT.
2. ASSEMBLE ON SOFT SURFACES TO PREVENT DAMAGE TO THE PRODUCT FINISH.
3. MAKE SURE ALL PARTS ARE INCLUDED BEFORE ASSEMBLY.
4. PLACE COMPUTER DESK AND STORAGE SHELF ON FLAT, LEVEL SURFACE. COMPUTER DESK AND STORAGE SHELF WILL NOT BE STABLE ON HIGH PILE CARPETING OR OUT OF LEVEL SURFACES. NOT FOR USE ON HIGH PILE CARPETING OR OTHER SIMILAR SURFACES.

ASSEMBLY TOOLS REQUIRED

SCREWDRIVER

HAMMER




Do you have any questions? Missing small parts or hardware? If you need assistance with the assembly of your COMPUTER DESK AND STORAGE SHELF please e-mail our Customer Service Department at: support@fourstari.com or call us at (508) 473-7688 or (800) 639-3803

Please include the following information in your email:
• Where item was purchased • Item, model, style or SKU number listed on instructions or box • Part number, description of the part and quantity needed
This information will help us get the proper part to you faster


PARTS AND HARDWARE LIST

NO	COMPUTER DESK PARTS LIST	QTY	NO	HARDWARE LIST	QTY
A	TOP PANEL	1 PC	1	38MM SCREW	12 PCS
B	LEFT SIDE PANEL	1 PC	2	12MM SCREW	4 PCS
C	RIGHT SIDE PANEL	1 PC	3	L-BRACKET	2 PCS
D	APRON PANEL	2 PCS	4	30MM WOODEN DOWEL	6 PCS
E	BOTTOM BACK PANEL	1 PC	5	WHITE GLUE	1 PC
F	SIDE CENTER PANEL	1 PC	6	NAIL LEG	4 PCS
G	SIDE BOTTOM PANEL	1 PC	7	LONG POLE	1 PC
STORAGE SHELF PARTS LIST			8	MEDIUM POLE	8 PCS
H	TOP PANEL	1 PC	9	SHORT POLE	1 PC
I	SHELF PANEL	2 PCS	10	INSERT CAP	5 PCS
			11	LEG	5 PCS




ASSEMBLY INSTRUCTIONS


STEP 1
INSTALL L-BRACKET (3) WITH 12MM SCREW (2) TO APRON PANEL (D).




STEP 2
INSTALL INSERT CAP (10) INTO TOP PANEL (A).




STEP 3
TIGHTEN SHORT POLE (2) TO TOP PANEL (A).




STEP 4
FASTEN APRON PANEL (D) & BOTTOM BACK PANEL (E) TO LEFT SIDE PANEL (B) & RIGHT SIDE PANEL (C) WITH 38MM SCREW (1).




STEP 5
INSERT WOODEN DOWEL (4) TO LEFT SIDE PANEL (B) & RIGHT SIDE PANEL (C) WITH WHITE GLUE (5).




STEP 6
ATTACH LEFT SIDE PANEL (B) & RIGHT SIDE PANEL (C) TO PANEL (A) WITH GLUE (5).




STEP 7
ATTACH APRON PANEL (D) TO TOP PANEL (A) WITH 12MM SCREW (2).




STEP 8
INSTALL NAIL LEG (6) TO THE BOTTOM SIDE OF LEFT SIDE PANEL (B) & RIGHT SIDE PANEL (C).




STEP 9
ATTACH SIDE CENTER PANEL (F) TO RIGHT SIDE PANEL (C) WITH 38MM SCREW (1). TIGHTEN POLE (7) TO SIDE CENTER PANEL (F).




STEP 10
ATTACH SIDE BOTTOM PANEL (G) TO RIGHT SIDE PANEL (C) WITH 38MM SCREW (1). TIGHTEN LEG (11) TO SIDE BOTTOM PANEL (G).




STEP 11
INSTALL INSERT CAP (10) INTO TOP PANEL (H).




STEP 12
TIGHTEN MEDIUM POLE (8) TO TOP PANEL (H).



STEP 13
TIGHTEN MEDIUM POLE (8) TO SHELF PANEL (I). TIGHTEN LEG (11) TO SHELF PANEL (I).



Recommended Maximum Weight



*Unit in Pound(lbs.)

CAUTION: MAXIMUM LOADING CAPACITY COMPUTER DESK FOR 40LBS, STORAGE SHELF FOR 45LBS
DO NOT SIT, STAND, LEAN, WALK CLIMB OR JUMP ON FURNITURE! FAILURE TO COMPLY WITH THIS CAUTION COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE!

This unit is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than the maximum weights indicated may result in instability causing possible injury. Furniture can tip over or break if improperly moved. Have a friend help to lift and carry the unit to its new location.