




*MODEL:* 12502792 10' x 13' SCREEN HOUSE




## **INSTRUCTION**






1. Using tubes No.7, 8 & 10, connectors "A", "C", "D", connect the tubes and connectors as shown above. Align the metal spring clip on tubes No.7 & 10 to the connectors A", "C", "D" and allow the spring clip to pop into the connector's slot. You will hear a 'TICK' sound when the metal spring is hooked in place properly. Please make sure the biggest diameter tube of connector "A", "C", & "D" face stright downward to the ground. Place tube No.8 between two tube No.7's to create the short side of the gazebo, Attach tube No.7 & 10 together as figure 1 shown.


2. Insert tube No.3 into tube No.4. Then insert tube No.4 which has the metal spring clip at the end into connectors "A" & "C", making sure the spring clip pops up and locks in place. Connect the No.3 tubes to a "B" connector. Connect the No.1 and No.2 tubes using connector "I". Now insert the connected tube No.1, 2 into connector "B". Make sure tube No.1 is connected to "B" connector correctly.





3. Insert connector "F" into one end of tube No.12 and hook "F" onto the middle part of tube No.8. Now put the other side of tube No.12 to connector "B". Repeat for other side of the gazebo. Connect tubes No.3 and No.11 together. Place tube No.3 into connector "D" and tube No.11 into connector "I".

4. Inser ttube No.5 to connectors "A", "C", "D". Spread the canopy on the ground. Hold and lift the canopy and lay down onto the frame. To avoid tearing apart or causing damage to the nettings, do not place the netting on the side of the frame and pull the canopy to the other side. Connect base "E" to tube No.6. With 4 or more people, raise the gazebo up (with canopy on) and connect tube No.6 to No.5.



5. There are velcro fasteners underneath the hood of the canopy. Fasten these to the tubes to secure the canopy onto the gazebo. For more security, hammer the steel stakes into the ground through the holes on the base as per illustration (a), or put one end of the rope through the corner circle and hithch another end onto the steel stake, then hammer into the ground as per illustration (b). To tighten the canopy, there are metal hooks sewn on the lower corner of the canopy on the bottom of the canopy. These can be hooked onto the holes on tube No.6.

## **CAUTIONS:**

This gazebo is designed for leisure use, not as a shelter against adverse weather conditions.

It is not meant to withstand all elements of the weather. Do not cook or ignite fireworks inside or near the gazebo.

Do you have any questions? Missing small parts or hardware? If you need assistance with the assembly of your 10' x 13' SCREEN HOUSE please e-mail our Customer Service Department at: support@fourstari.com or call us at (508) 435-4830 or (800) 639-3803

Please include the following information in your email:

- · Where item was purchased
- Item, model, style or SKU number listed on instructions or box
- Part number, description of the part and quantity needed

This information will help us get the proper part to you faster

